

## Sample preparation protocol

When preparing your samples for our analytical pipeline please prepare them according to this protocol.

- 1) Centrifuge an appropriate volume of fresh cell culture sample for 5-10 min at 200 x g.
- 2) Filter supernatant with a 0.2 µm filter into an appropriate tube/container.
- 3) Store your samples at -20 °C and ship on dry ice.

### Important information:

- You should prepare your samples according to this sample preparation protocol before sending them to us.
- Your samples have to be free of bacterial and viral contamination.
- Your samples have to be non-hazardous and classified as Biosafety Level 1.
- Please attach the sample declaration sheet to your samples.
- Most samples should be sent frozen on dry ice/wet ice!
- For accurate information on how and where to send your samples please contact us directly:

web: [www.xell.ag](http://www.xell.ag)  
mail: [info@xell.ag](mailto:info@xell.ag)  
phone: +49 (0)521-96989-200  
fax: +49 (0)521-96989-201